


eGalax Touch Driver INSTALL SOP


20170913-1

Other Linux Distribution such as Debian or Fedora please checks if the serial ports enable in kernel more than 6 ports. The default for touch controller is ttyS4.



```
fae@debian: ~  
File Edit Tabs Help  
fae@debian:~$ ls /dev/ttyS*  
/dev/ttyS0 /dev/ttyS1 /dev/ttyS2 /dev/ttyS3 /dev/ttyS4 /dev/ttyS5  
fae@debian:~$
```


Check from /dev/ttyS0 to ttyS5 is existing. If less than 6 ports. Please modify /boot/grub/grub.cfg and add “8250.nr_uarts=5” in the end of vmlinuz as below than save and reboot. After reboot check again is 6 serial port already enable.



```
set linux_gfx_mode=  
export linux_gfx_mode  
menuentry 'Debian GNU/Linux' --class debian --class gnu-linux --class gnu --class os $menuentry_id_option 'gnulinux-simple-15  
  load_video  
  insmod gzio  
  if [ x$grub_platform = xxen ]; then insmod xzio; insmod lzopio; fi  
  insmod part_msdos  
  insmod ext2  
  set root='hd0,msdos1'  
  if [ x$feature_platform_search_hint = xy ]; then  
    search --no-floppy --fs-uuid --set=root --hint-ieee1275='ieee1275//disk@0,msdos1' --hint-bios=hd0,msdos1 --hint-efi$  
  else  
    search --no-floppy --fs-uuid --set=root 1307d5b3-fe8e-42ae-8247-8dd3849218bc  
  fi  
  echo 'Loading Linux 4.9.0-3-686 ...'  
  linux /boot/vmlinuz-4.9.0-3-686 root=/dev/sda1 ro quiet 8250.nr_uarts=6  
  echo 'Loading initial ramdisk ...'  
  initrd /boot/initrd.img-4.9.0-3-686
```


Then follow below steps to install the touch driver.

1. Copy the driver (eGTouch_v2.5.4300.L-x.zip) onto Unit.
2. Unzip driver below the catalogue of eGTouch_v2.5.4300.L-x



```
root@PT6300: ~  
root@PT6300:~# ls  
Desktop    eGTouch_v2.5.4330.L-x    Pictures  Videos  
Documents  eGTouch_v2.5.4330.L-x.zip Public  
Downloads  Music                    Templates  
root@PT6300:~#
```

3. Going to the catalogue of eGTouchv2.5.4300.L-x



```
root@PT6300: ~/eGTouch_v2.5.4330.L-x  
  inflating: eGTouch_v2.5.4330.L-x/Guide/EETI_eGTouch_Linux_Programming_Guide_v2  
.5g.pdf  
  inflating: eGTouch_v2.5.4330.L-x/Guide/EETI_eGTouch_Utility_Guide_for_Linux_v1  
.03.pdf  
  inflating: eGTouch_v2.5.4330.L-x/Guide/GetEvent.c  
  inflating: eGTouch_v2.5.4330.L-x/Guide/Linux_eGTouch_Release_Note.txt  
  inflating: eGTouch_v2.5.4330.L-x/Patent_Declaration/EETI_Declaration_and_Disc  
laimer.pdf  
  inflating: eGTouch_v2.5.4330.L-x/Patent_Declaration/eula.pdf  
  inflating: eGTouch_v2.5.4330.L-x/readme.txt  
  inflating: eGTouch_v2.5.4330.L-x/Rule/52-egalax-virtual.conf  
  inflating: eGTouch_v2.5.4330.L-x/Rule/eGTouchU.desktop  
extracting: eGTouch_v2.5.4330.L-x/Rule/eGTouchU.png  
  inflating: eGTouch_v2.5.4330.L-x/Rule/rc.local  
  inflating: eGTouch_v2.5.4330.L-x/Rule/serio_raw.sh  
  inflating: eGTouch_v2.5.4330.L-x/setup.sh  
root@PT6300:~# ls  
Desktop    eGTouch_v2.5.4330.L-x    Pictures  Videos  
Documents  eGTouch_v2.5.4330.L-x.zip Public  
Downloads  Music                    Templates  
root@PT6300:~# cd eGTouch_v2.5.4330.L-x  
root@PT6300:~/eGTouch_v2.5.4330.L-x# ls  
eGTouch32  eGTouch64  Guide  Patent_Declaration  readme.txt  Rule  setup.sh  
root@PT6300:~/eGTouch_v2.5.4330.L-x#
```

4. Running the installation program (bash setup.sh)

```
root@PT6300: ~/eGTouch_v2.5.4330.L-x
inflating: eGTouch_v2.5.4330.L-x/Guide/GetEvent.c
inflating: eGTouch_v2.5.4330.L-x/Guide/Linux_eGTouch_Release_Note.txt
inflating: eGTouch_v2.5.4330.L-x/Patent_Declaration/EETI_Declaration_and_Disc
ainer.pdf
inflating: eGTouch_v2.5.4330.L-x/Patent_Declaration/eula.pdf
inflating: eGTouch_v2.5.4330.L-x/readme.txt
inflating: eGTouch_v2.5.4330.L-x/Rule/52-egalax-virtual.conf
inflating: eGTouch_v2.5.4330.L-x/Rule/eGTouchU.desktop
extracting: eGTouch_v2.5.4330.L-x/Rule/eGTouchU.png
inflating: eGTouch_v2.5.4330.L-x/Rule/rc.local
inflating: eGTouch_v2.5.4330.L-x/Rule/serio_raw.sh
inflating: eGTouch_v2.5.4330.L-x/setup.sh
root@PT6300:~# ls
Desktop  eGTouch_v2.5.4330.L-x  Pictures  Videos
Documents eGTouch_v2.5.4330.L-x.zip  Public
Downloads Music  Templates
root@PT6300:~# cd eGTouch_v2.5.4330.L-x
root@PT6300:~/eGTouch_v2.5.4330.L-x# ls
eGTouch32 eGTouch64 Guide Patent_Declaration readme.txt Rule setup.sh
root@PT6300:~/eGTouch_v2.5.4330.L-x# bash setup.sh

(*) Driver installer for touch controller
(*) Script Version = 1.04.4330

(I) Check user permission: root, you are the supervisor.
(I) Platform application binary interface = x86_64
(W) X server detected.

Declaration and Disclaimer
The programs, including but not limited to software and/or firmware (hereinafter
referred to "Programs" or "PROGRAMS", are owned by eGalax_eMPIA Technology Inc.
(hereinafter referred to EETI) and are compiled from EETI Source code. EETI her
eby grants to licensee a personal, non-exclusive, non-transferable license to co
py, use and create derivative works of Programs for the sole purpose in conjunct
ion with an EETI Product, including but not limited to integrated circuit and/or
controller. Any reproduction, copies, modification, translation, compilation, a
pplication, or representation of Programs except as specified above is prohibite
d without the express written permission by EETI.
```

5. Input "Y"

```
referred to "Programs" or "PROGRAMS", are owned by eGalax_eMPIA Technology Inc.
(hereinafter referred to EETI) and are compiled from EETI Source code. EETI her
eby grants to licensee a personal, non-exclusive, non-transferable license to co
py, use and create derivative works of Programs for the sole purpose in conjunct
ion with an EETI Product, including but not limited to integrated circuit and/or
controller. Any reproduction, copies, modification, translation, compilation, a
pplication, or representation of Programs except as specified above is prohibite
d without the express written permission by EETI.

Disclaimer: EETI MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD
TO PROGRAMS, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTAB
ILITY AND FITNESS FOR A PARTICULAR PURPOSE. EETI reserves the right to make chan
ges without further notice to the Programs described herein. Licensee agrees tha
t EETI does not assume any liability, damages or costs, including but not limite
d to attorney fees, arising out from Programs themselves or those arising out fr
om the application or combination Programs into other products or circuit. The u
se or the inclusion of EETI's Programs implies that the Licensee assumes all ris
k of such use and in doing so indemnifies EETI against all charges, including bu
t not limited to any claims to infringement of any third party's intellectual pr
operty right.

Do you agree with above patent declaration?
[Y] Yes, I agree. [N] No, I don't agree.
Y
```

6. Input 1 (RS232)

```
root@PT6300: ~/eGTouch_v2.5.4330.L-x 10:40 PM Guest
(*) Driver installer for touch controller
(*) Script Version = 1.04.4330

(I) Check user permission: root, you are the supervisor.
(I) Platform application binary interface = x86_64
(W) X server detected.

Declaration and Disclaimer
The programs, including but not limited to software and/or firmware (hereinafter referred to "Programs" or "PROGRAMS", are owned by eGalax_eMPIA Technology Inc. (hereinafter referred to EETI) and are compiled from EETI Source code. EETI hereby grants to licensee a personal, non-exclusive, non-transferable license to copy, use and create derivative works of Programs for the sole purpose in conjunction with an EETI Product, including but not limited to integrated circuit and/or controller. Any reproduction, copies, modification, translation, compilation, application, or representation of Programs except as specified above is prohibited without the express written permission by EETI.

Disclaimer: EETI MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO PROGRAMS, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. EETI reserves the right to make changes without further notice to the Programs described herein. Licensee agrees that EETI does not assume any liability, damages or costs, including but not limited to attorney fees, arising out from Programs themselves or those arising out from the application or combination Programs into other products or circuit. The use or the inclusion of EETI's Programs implies that the Licensee assumes all risk of such use and in doing so indemnifies EETI against all charges, including but not limited to any claims to infringement of any third party's intellectual property right.

Do you agree with above patent declaration?
[Y] Yes, I agree. [N] No, I don't agree.
y

(Q) Which interface controller do you use?
(I) [1] RS232 [2] USB [3] PS2 : 1
(I) Please confirm the touch controller is linked with your device. Press [Enter] key to continue.....

```

7. Input 1 (Default)

```
root@PT6300: ~/eGTouch_v2.5.4330.L-x 10:41 PM Guest
referred to "Programs" or "PROGRAMS", are owned by eGalax_eMPIA Technology Inc. (hereinafter referred to EETI) and are compiled from EETI Source code. EETI hereby grants to licensee a personal, non-exclusive, non-transferable license to copy, use and create derivative works of Programs for the sole purpose in conjunction with an EETI Product, including but not limited to integrated circuit and/or controller. Any reproduction, copies, modification, translation, compilation, application, or representation of Programs except as specified above is prohibited without the express written permission by EETI.

Disclaimer: EETI MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO PROGRAMS, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. EETI reserves the right to make changes without further notice to the Programs described herein. Licensee agrees that EETI does not assume any liability, damages or costs, including but not limited to attorney fees, arising out from Programs themselves or those arising out from the application or combination Programs into other products or circuit. The use or the inclusion of EETI's Programs implies that the Licensee assumes all risk of such use and in doing so indemnifies EETI against all charges, including but not limited to any claims to infringement of any third party's intellectual property right.

Do you agree with above patent declaration?
[Y] Yes, I agree. [N] No, I don't agree.
y

(Q) Which interface controller do you use?
(I) [1] RS232 [2] USB [3] PS2 : 1
(I) Please confirm the touch controller is linked with your device. Press [Enter] key to continue.....
.

(I) Found /etc/rc.local file.
(I) Found uinput at path /dev/uinput
(I) Place eGTouch driver archive to /usr/local/eGTouch64withX.
(I) Create eGTouch daemon shortcut in /usr/bin.
(I) Create eGTouchU tool shortcut in /usr/bin.
(I) Create eCalib tool shortcut in /usr/bin.
(I) Detach eGTouchD daemon execution from /etc/rc.local.
(I) Append eGTouch daemon execution into /etc/rc.local.

(Q) How many controllers do you want to plug-in to system? [1-10]
(I) Default [1]:1

```

8. Installation completed, restart unit.

```
root@PT6300: ~/eGTouch_v2.5.4330.L-x
Disclaimer: EETI MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO PROGRAMS, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. EETI reserves the right to make changes without further notice to the Programs described herein. Licensee agrees that EETI does not assume any liability, damages or costs, including but not limited to attorney fees, arising out from Programs themselves or those arising out from the application or combination Programs into other products or circuit. The use or the inclusion of EETI's Programs implies that the Licensee assumes all risk of such use and in doing so indemnifies EETI against all charges, including but not limited to any claims to infringement of any third party's intellectual property right.

Do you agree with above patent declaration?
[Y] Yes, I agree. [N] No, I don't agree.
y

(Q) Which interface controller do you use?
(I) [1] RS232 [2] USB [3] PS2 : 1
(I) Please confirm the touch controller is linked with your device. Press [Enter] key to continue.....
.

(I) Found /etc/rc.local file.
(I) Found uinput at path /dev/uinput
(I) Place eGTouch driver archive to /usr/local/eGTouch64withX.
(I) Create eGTouch daemon shortcut in /usr/bin.
(I) Create eGTouchU tool shortcut in /usr/bin.
(I) Create eCalib tool shortcut in /usr/bin.
(I) Detach eGTouchD daemon execution from /etc/rc.local.
(I) Append eGTouch daemon execution into /etc/rc.local.

(Q) How many controllers do you want to plug-in to system? [1-10]
(I) Default [1]:1
1
(I) Device Nums is set to 1
(W) Found udev rule: 52-egalax-virtual.conf.
(I) Create eGTouchU shortcut in application list.

(I) Driver installation completed. Setup version 1.04.4330.
(I) Please reboot the system.

root@PT6300: ~/eGTouch_v2.5.4330.L-x#
```

Troubleshooting.

For Debian 9.1


1. Default only enable 4 ttyS*, Please modify /boot/grub/grub.cfg to enable upto 6 ttyS*
2. Debian 9 disables the rc-local service in default.

To start eGTouchD in rc.local service, please manually add a file: /etc/rc.local

Then content is:

```
#!/bin/sh
/usr/bin/eGTouchD
exit 0
```

For example:



And run below command to grant it executable permission:

```
chmod +x /etc/rc.local
```

Run below command to enable rc-local service, to make system launch eGTouchD driver when booting.

```
systemctl start rc-local
```